

# NORMAL POSITION



Normal **PARKING** position, kerb points to SQUARE (and left handles touch kerb)



Normal **DRIVING** position, kerb points to TRIANGLE (left handles away from kerb)



**Parking on RIGHT**, kerb points to PAUSE ["II"] symbol (and right handles touch kerb)  
Centre of road also points here when waiting, at "left of centre", to turn right



Minimum **passing** clearance (about ½ m from parked car), tyres of parked car make